



[Knowledgebase](#) > [Smartwatches](#) > [Reebok Icon Troubleshooting and Information](#) > [Product Features](#) > [Customizing the Down Button on Your Reebok Icon](#)

Customizing the Down Button on Your Reebok Icon

Inas Laghzaoui - 2025-08-20 - [Comments \(0\)](#) - [Product Features](#)

Your Reebok Icon lets you assign a specific action to the bottom physical button, streamlining your access to key features.

How to Customize the Down Button

- Open Settings on your watch.
- Navigate down.
- Select the Down Button option.
- Choose the desired action, such as opening the Activity List or other available shortcuts.

This allows quick access to your most-used functions with a simple press, saving time and enhancing your experience.