



[Knowledgebase](#) > [Smartwatches](#) > [Reebok Icon Troubleshooting and Information](#) > [Charging & Battery](#) > [Battery Safety Guidelines](#)

## Battery Safety Guidelines

Inas Laghzaoui - 2025-08-20 - [Comments \(0\)](#) - [Charging & Battery](#)

Your Reebok Icon contains a built-in lithium battery. Following these safety tips will help ensure safe use and long battery life.

### Do Not Attempt to Replace the Battery

The battery is **not designed to be replaced by the user**.

All battery-related operations must be carried out **only** by Reebok/Vitalist authorized service providers. Attempting to open the device or replace the battery yourself may cause serious damage or create a safety hazard.

### Keep Away From Heat Sources

To avoid overheating, **do not expose the device or battery to:**

- Direct sunlight for long periods
- Open flames
- Heaters, ovens, or stoves
- Microwaves

### Avoid Impact or Damage

Do not drop, puncture, squeeze, or crush the device.

Damage to the battery can cause it to **leak, overheat, catch fire, or explode**.

### In Case of Battery Leakage

If the battery leaks:

- **Do not touch the liquid** with your skin or eyes.
- If contact occurs, **rinse immediately with clean water**.
- Seek **medical attention** as soon as possible.

### Use Only Approved Chargers

Always use the **official Reebok (Vitalist-approved) charging cable and power adapter**.

Using unapproved or incompatible chargers may:

- Damage the battery
- Cause overheating or fire
- Result in burns or injury

**Tip:** Stop using the device immediately if you notice swelling, discoloration, strange smells, or excessive heat while charging.

Your safety is always a priority. If you ever have doubts about the battery or charging accessories, please contact our Support team.