

Knowledgebase > Pre-Purchase Inquiry > Reebok Icon > Accessibility > Skin Sensitivity & Allergies

# **Skin Sensitivity & Allergies**

Inas Laghzaoui - 2025-08-28 - Comments (0) - Accessibility

#### Using Reebok Icon Safely for Sensitive Skin

Reebok wearables are designed for daily use, including workouts and active lifestyles. If you have sensitive skin or allergies, the following guidance will help you wear your device safely:

#### **Potential Irritation:**

- Some users may experience redness, itching, or irritation from watch bands, especially during exercise
  or in hot/humid conditions.
- Irritation is more likely if the watch is worn tightly or if moisture builds up under the band.

#### **Preventive Measures:**

- Keep your watch and bands clean by wiping them regularly with a soft, damp cloth.
- Avoid using harsh soaps or chemicals that may leave residues.
- Dry the wrist and watch band thoroughly after sweating, swimming, or showering.
- Consider hypoallergenic bands made of silicone, textile, or leather designed for sensitive skin.

### **Best Practices:**

- Adjust band fit to be snug but not tight, allowing the skin to breathe.
- Rotate wrists if you wear the watch continuously to reduce prolonged pressure.
- Monitor your skin regularly for signs of irritation.

# When to Seek Medical Advice:

- Stop wearing the device immediately if redness, itching, or rash persists.
- Consult a healthcare professional if symptoms continue, worsen, or if you suspect an allergic reaction.

## Disclaimer:

Reebok wearables are not medical devices. This guidance is for comfort and safe use, not for diagnosis
or treatment of skin conditions.

For additional assistance or to explore hypoallergenic band options, contact Reebok Wearables Support.